

Acid Salt 829

Liquid Soak Cleaner Component
Technical Data

GENERAL DESCRIPTION

Acid Salt 829 is a dry powder containing acid salts and surface active agents. **Acid Salt 829** is for use with water on all metal as a replacement for mineral acids.

NORMAL USE

Concentration	2 – 32 oz. per gallon. (15 – 360 g per L)
Temperature	140 – 190° F (60 - 88° C)
Time	15 seconds to 5 minutes

SUGGESTED OPERATING CONDITIONS

Cold rolled steel prior to nickel:

Operate at 16 oz. per gallon (120 g per L) at room temperature for 15 seconds to 2 minutes.

Hot rolled steel, welded steel or heat treated parts:

Operate at 16 oz. per gallon (120 g per L) at 130° F (55° C) for 30 seconds to 5 minutes.

Zinc Die Castings:

Operate at 4 oz. per gallon (30 g per L) at room temperature for 30 seconds.

Copper Plated or Buffed Brass:

Operate at 8 oz. per gallon (60 g per L) at room temperature for 10 seconds to 1 minute.

Nickel Activation:

Operate at 16 oz. per gallon (120 g per L) at 120° F (49° C) for 1 minute.

Chrome Stripping:

Operate at 16 to 32 oz. per gallon (120 – 240 g per L) at 180° F (82° C) for 1 to 3 minutes.

Activation and scale removal using current:

Cathode (work as cathode)

Current Density	45 – 100 ASF (4.5 – 10 ASD)
Voltage	1 – 6 Volts
Anodes	Graphite (AGR Type)
Anode/Work Area	2 : 1

EQUIPMENT REQUIREMENTS

Tanks:

Koroseal lined tank satisfactory to 150° F (66° C). High temperature rubber is recommended for temperatures exceeding 150° F (66° C). At room temperature, rubber, polyethylene, PVC or polypropylene are satisfactory.

Heating Coils:

Karbate, Graphite, Teflon

Ventilation:

Positive ventilation is required when solution is heated or when current is used. All ducting and blowers must be chemical resistant.

SOLUTION MAKE-UP

To make solution, fill tank 2/3 full of water and stir in dry salts until powder is dissolved. After **Acid Salt 829** is added to the solution, adjust the level and temperature to operating conditions.

NORMAL CONTROL

Analytical Method (Equipment available from Chautauqua Chemicals Co.)

1. Pipette a 10 mL sample into a 250 mL Erlenmeyer flask.
2. Add 50 mL of distilled water.
3. Add 3-5 drops of bromcresol green indicator.
4. Titrate with 0.50N sodium hydroxide until solution turns green.
5. Calculation: Concentration of **Acid Salt 829** (ounces per gallon) = mLs of 0.50N NaOH x 0.98
Concentration of **Acid Salt 829** (grams per liter) = mLs of 0.50N NaOH x 7.34

HANDLING AND SAFETY CONSIDERATIONS

Consult MSDS sheet on this product for handling considerations, hazard information, and first aid procedures.

OTHER INFORMATION

No warranty, expressed or implied of merchantability fitness for a particular purpose or otherwise, is made. Buyer assumes all risk of use, storage and handling. Chautauqua Chemicals Company, Inc. shall not be made liable for any incidental or consequential damages arising directly or indirectly in connection with the purchase, storage, handling or disposal of this product.

TDS Number:
Revision Date:

50551C
July 23, 2014

